

LUNERA HPS LAMP GEN 2


Installation Guide

Horizontal, Mogul (E39 / EX39)



Installation Instructions

- 1. Power OFF the High-Pressure Sodium (HPS) downlight fixture into which you will install the LUNERA HPS LED Lamp.**
Wait for approximately 10 minutes before touching the existing HPS bulb.
- 2. Carefully remove the existing HPS bulb.**
Unscrew the lamp from the base slowly to avoid breakage. Be sure to properly recycle the HPS lamp.
- 3. Make sure the existing bulb wattage matches the Lunera HPS LED Lamp equivalent wattage.**
Check the lamp enclosure to ensure the HPS LED Lamp matches the lamp being replaced... i.e. HPS LED Lamp MULTIW is replacing a 400W, 310W, 250W, or 200W E39 Mogul high-pressure sodium. If the HPS LED Lamp model does not match the rated fixture wattage, stop. Do not install.









Lunera HPS LED Lamp
MULTIW

The Lunera HPS LED Lamp is available with a CCT of 4000K.

- 4. Install the HPS LED Lamp into the existing E39/EX39 mogul base socket.**
If the lamp does not seat properly, do not apply force. Check to make sure the fixture has the E39/EX39 mogul required socket.
- 5. Turn ON power.**
If the Lunera HPS LED Lamp flickers, strobos, or fails on installation, immediately Turn OFF power. The HPS LED Lamp may not be compatible with the intended installation.






Intended Applications

The Lunera HPS LED Lamp is designed to replace HPS lamps in the following compatible applications.

<p>Wattage Compatibilities</p> <p>Lunera HPS LED Lamp MULTIW</p>  <p>Replaces</p> <p>400W HPS or 310W HPS or 250W HPS or 200W HPS</p> 	<p>Sockets</p> <p>E39 Mogul</p>  <p>EX39 Mogul</p> 	<p>Power Source</p> <p>Magnetic HPS Ballast</p> 	<p>Mount</p> <p>Horizontal Mount</p> 
			<p>Fixture</p> <p>With or Without (sealed) Lens</p>

Incompatible Applications

Installation of the Lunera HPS LED Lamp in **INCOMPATIBLE** HPS applications may cause the Lunera HPS LED Lamp flicker, strobe, or fail entirely.

<p>Wattage Compatibilities</p> <p>Lunera HPS LED Lamp MULTIW</p>  <p>NOT acceptable to replace <i>any lamp or ballast wattage EXCEPT what is listed above in the intended applications including wattage and lamp type.</i></p> 	<p>Power Source</p> <p>Electronic Ballast</p>  <p>Direct Line Voltage</p> 	<p>Socket</p> <p>E26 Medium</p> 
--	---	---

