









Intended Applications

The Lunera HID LED 360 lamp is designed to replace MH and HPS lamps in the following compatible applications:

Wattage Compatibilities	Sockets	Power Source	Mount
HID LED 360 Mogul (E39) Base Replaces  = 250W-70W MH or HPS	E39 / EX39 Mogul 	Magnetic HID Ballast 	360° Illumination Vertical/Horizontal
HID LED 360 Medium (E26) Base  = 250W-70W MH or HPS	E26 Medium 		Fixture Type  Architectural Post Top

Incompatible Applications

Installation of the Lunera HID LED 360 lamp in **INCOMPATIBLE** applications may cause the lamp to flicker, strobe, or fail entirely (Installation in the following applications will VOID the warranty.)

Wattage Incompatibilities Lunera HID LED 360 Mogul (E39) Base NOT acceptable to replace <i>any</i> lamp or ballast wattage above 400W.  Lunera HID LED 360 Medium (E26) Base <i>The Lunera HID LED 360 lamp Medium (E26) Base does NOT support operation with 600W or 1000W HID ballasts.</i> 	Incompatible Power Source Electronic HID Ballast External LED Driver CWA Ballast Above 400W High-Reactance HX Ballast Emergency Battery Backup
---	---

Product warranty will be voided if lamp installed while power is "ON" to the fixture.

General Safety Information

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

DANGER - RISK OF SHOCK - TURN POWER OFF BEFORE INSTALLATION

WARNING - IF THE LAMP OR LUMINAIRE EXHIBITS UNDESIRABLE OPERATION (BUZZING, FLICKERING, ETC) IMMEDIATELY TURN OFF POWER, REMOVE LAMP FROM LUMINAIRE AND CONTACT MANUFACTURER.

CETTE LAMPE OPERE SEULEMENT AVEC LE BALLAST ELECTRONIQUE. SI LA LAMPE NE S'ALLUME PAS QUAND L'APPAREIL D'ECLAIRAGE ACTIVE, ENLEVEZ LA LAMPE DE L'APPAREIL D'ECLAIRAGE ET CONTACTEZ LE FABRICANT DE LAMPE OU UN ELECTRICIEN QUALIFE.

CAUTION - RISK OF FIRE - IF INSTALLING THIS LAMP IN A PRE-HEAT LUMINAIRE, REMOVE THE AUTOMATIC STARTERS FROM THEIR HOLDERS BEFORE INSTALLING THE LAMP.

ATTENTION RISQUE DE FEU - SI LA LAMPE OU LE LUMINAIRE MONTRE DESIGNEES D'OPERATION UNDESIRABLE (BRUIT, VIBRATION, CLIGNOTEMENT, ETC.), ALORS COUPER IMMEDIATEMENT LE COURANT ET ENLEVER LA LAMPE DE L'APPAREIL D'ECLAIRAGE ENTRER EN CONTACT AVEC LE FABRICANT.

THIS LAMP IS NOT INTENDED FOR USE WITH EXTERNAL LED DRIVER, ELECTRONIC HID, OR HIGH-REACTANCE (HX) BALLASTS.

CAUTION - DO NOT INSTALL THIS LAMP TO HID BALLASTS RATED ABOVE 400W. THIS LAMP SUPPORTS OPERATION WITH CWA HID BALLASTS ONLY.

THIS DEVICE IS NOT INTENDED FOR USE WITH EMERGENCY EXITS OR NOT FOR EMERGENCY LIGHTING.

MIN. LAMP COMPARTMENT DIMENSIONS; MIN. 20.3 CM (8") DIAM. AT THE BOTTOM, 20.3 CM (8") DIAM. ON TOP. 40.6 CM (16") DEPTH.

LUNERA HID LED 360 HAS BEEN EVALUATED FOR OPERATION WITH THE FOLLOWING ANSI BALLASTS: H37, H39, M57, M58, M59, M90, M102, M107, S50, S51, S54, S56, S67, S55, S66